

## SOS Easy Read Guide to Hearing Aid Care



### Guide to Hearing Aid Care

Blue – Left Ear Red – Right Ear	
Store Hearing Aid in safe place that's cool and dry	SECTION REAL
Change batteries every 2 weeks. Battery Size 13 (orange), Size 312 (brown), Size 10 (yellow), Size 675 (blue)	
<b>Warning</b> Hearing aid beeps- when battery is running low	
<b>Switch off</b> when not in use	CONTRACTOR ON THE CONTRACTOR OFFICE

# **BATTERYS** Available in any chemist or **Deafhear.ie** 44 Friary St – Every Monday 9am-<u>5pm</u> (Not available from HSE) Never force battery door closed (Battery door should close easily if battery inserted correctly) **To Turn on Hearing Aid:** Close Battery Door. **To Turn off Hearing Aid:** Open Battery Door (do this when hearing aid is not in use to save battery)

#### **Cleaning Hearing Aid**

Remove earwax from hearing aid.

Clean hearing aid using small brush or cloth that came with it.

Accumulated earwax may prevent sound from travelling from the hearing aid into the ear and cause whistling or feedback







#### Earwax

Earwax build-up can block sound to the ear. Accumulation of wax can cause whistling or feedback.

If volume diminishes earwax could be the problem. Ensure service user who have a build-up of wax follow care plan for same and have their ears syringed.



<b>Don't wear</b> your hearing aid in the shower	
<b>Don't wear</b> your hearing aid when swimming.	
<b>Don't wear</b> your hearing aid when using a hair dryer or hair spray	
<b>Telephone</b> Hold phone to Hearing Aid sitting on top of ear	
Never allow hearing aid to get wet	

### Repairs



No charge for repair or services.	Free
Please include your contact details if you are sending your hearing aid for repair	NAME and ADDRESS
Maintenance: Hearing Aids can be brought to Deafhear, Friary St., every 2 to 3 months for servicing. Can be sent once a year for service to ensure it is working well.	